

Vehicle	SubVehicle	Year	SystemName	FunctionName	SubFunction	Version
Jaguar	XX	2006-2009	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ADCM - Adaptive damping control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ADCM - Adaptive damping control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ADCM - Adaptive damping control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ADCM - Adaptive damping control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	HCM - Headlamp control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	HCM - Headlamp control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	HCM - Headlamp control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	HCM - Headlamp control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	VIM - Vehicle immobilizer control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ICS - Impact classification system	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ICS - Impact classification system	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICS - Impact classification system	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICS - Impact classification system	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	FSJB - Central junction box (body control module)	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	FSJB - Central junction box (body control module)	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FSJB - Central junction box (body control module)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FSJB - Central junction box (body control module)	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	FTCM - Folding top control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	FTCM - Folding top control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FTCM - Folding top control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FTCM - Folding top control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ICM - Infotainment control module.	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ICM - Infotainment control module.	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICM - Infotainment control module.	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICM - Infotainment control module.	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ICP - Integrated control panel	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ICP - Integrated control panel	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICP - Integrated control panel	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ICP - Integrated control panel	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	KVM - Keyless vehicle module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	KVM - Keyless vehicle module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	KVM - Keyless vehicle module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	KVM - Keyless vehicle module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PAM - Parking assist control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	PDM - Passenger's door module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	PDM - Passenger's door module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PDM - Passenger's door module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PDM - Passenger's door module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	PSM - Passenger's seat module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	PSM - Passenger's seat module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PSM - Passenger's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	PSM - Passenger's seat module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	HVAC - Heating ventilation and air conditioning control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	HVAC - Heating ventilation and air conditioning control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	HVAC - Heating ventilation and air conditioning control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	HVAC - Heating ventilation and air conditioning control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	RSJB - Auxiliary junction box (body control module B)	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	RSJB - Auxiliary junction box (body control module B)	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	RSJB - Auxiliary junction box (body control module B)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	RSJB - Auxiliary junction box (body control module B)	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	FCDIM - Front control/display interface module (high level display front)	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	FCDIM - Front control/display interface module (high level display front)	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FCDIM - Front control/display interface module (high level display front)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FCDIM - Front control/display interface module (high level display front)	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	ACM - Audio front control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	ACM - Audio front control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ACM - Audio front control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	ACM - Audio front control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	AAM - Audio amplifier module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	AAM - Audio amplifier module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	AAM - Audio amplifier module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	AAM - Audio amplifier module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	NCM - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	NCM - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	NCM - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	NCM - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	SRM - Satellite audio unit module	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	SRM - Satellite audio unit module	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	SRM - Satellite audio unit module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	SRM - Satellite audio unit module	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	BPM - Cellular telephone control module (bluetooth telephone module)	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	BPM - Cellular telephone control module (bluetooth telephone module)	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	BPM - Cellular telephone control module (bluetooth telephone module)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	BPM - Cellular telephone control module (bluetooth telephone module)	Live Data		V1.00.001 or higher
Jaguar	XX	2006-2009	FLR - Forward looking radar	ECU Information		V1.00.001 or higher
Jaguar	XX	2006-2009	FLR - Forward looking radar	Read Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	FLR - Forward looking radar	Erase Codes		V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions		Parking brake release to service position	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions		Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions		Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions		Tire pressure monitor receiver calibration.	V1.00.001 or higher

Jaguar	XX	2006-2009	Special functions	Tire pressure monitoring tire pressure sensor test	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Program keys.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Erase all existing keys	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Verify keys	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Lateral accelerometer calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Special functions	Headlamp and axle sensor calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Speed control alignment	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Idle speed test.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Purge valve self test	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Fuel prime routine	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Flight recorder.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Pressure sensor calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Program keys.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Erase all existing keys	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Verify keys	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Start authorisation status	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Headlamp and axle sensor calibration.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Vehicle reset	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Odometer calibration	V1.00.001 or higher
Jaguar	XX	2006-2009	Service	Alarm trigger history	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Adaptive damping control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Driver's seat module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Folding top control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Headlamp control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Heating ventilation and air conditioning control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Passenger's seat module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Tire pressure monitor module	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Vehicle immobilizer control module (steering column lock)	V1.00.001 or higher
Jaguar	XX	2006-2009	Programming/Customization	Mirror personalisation features	V1.00.001 or higher
Jaguar	XX	2010-2015	PCM - Powertrain control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	PCM - Powertrain control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	PCM - Powertrain control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	PCM - Powertrain control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	TCM - Transmission control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	TCM - Transmission control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	TCM - Transmission control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	TCM - Transmission control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	ABS - ABS control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	ABS - ABS control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ABS - ABS control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ABS - ABS control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	RCM - Restraints control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	RCM - Restraints control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	RCM - Restraints control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	RCM - Restraints control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	IPC - Instrument cluster control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	IPC - Instrument cluster control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	IPC - Instrument cluster control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	IPC - Instrument cluster control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	PBM - Parking brake control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	PBM - Parking brake control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	PBM - Parking brake control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	PBM - Parking brake control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	TPM - Tire pressure monitor module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	TPM - Tire pressure monitor module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	TPM - Tire pressure monitor module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	TPM - Tire pressure monitor module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	CCM - Speed control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	CCM - Speed control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	CCM - Speed control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	CCM - Speed control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	ADCM - Adaptive damping control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	ADCM - Adaptive damping control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ADCM - Adaptive damping control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ADCM - Adaptive damping control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	HCM - Headlamp control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	HCM - Headlamp control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	HCM - Headlamp control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	HCM - Headlamp control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	VIM - Vehicle immobilizer control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	VIM - Vehicle immobilizer control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	VIM - Vehicle immobilizer control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	VIM - Vehicle immobilizer control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	GSM - Gear shift module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	GSM - Gear shift module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	GSM - Gear shift module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	GSM - Gear shift module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	ICS - Impact classification system	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	ICS - Impact classification system	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ICS - Impact classification system	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	ICS - Impact classification system	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	OCS - Restraints occupant classification system module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	OCS - Restraints occupant classification system module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	OCS - Restraints occupant classification system module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	OCS - Restraints occupant classification system module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	RDCM - Rear differential control module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	RDCM - Rear differential control module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	RDCM - Rear differential control module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	RDCM - Rear differential control module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	DCSM - Driver's climate seat module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	DCSM - Driver's climate seat module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DCSM - Driver's climate seat module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DCSM - Driver's climate seat module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	XX	2010-2015	FSJB - Central junction box (body control module)	ECU Information	V1.00.001 or higher
Jaguar	XX	2010-2015	FSJB - Central junction box (body control module)	Read Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	FSJB - Central junction box (body control module)	Erase Codes	V1.00.001 or higher
Jaguar	XX	2010-2015	FSJB - Central junction box (body control module)	Live Data	V1.00.001 or higher

Jaguar	XX	2010-2015	FTCM - Folding top control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	FTCM - Folding top control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	FTCM - Folding top control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	FTCM - Folding top control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	ICM - Infotainment control module.	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	ICM - Infotainment control module.	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	ICM - Infotainment control module.	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	ICM - Infotainment control module.	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	ICP - Integrated control panel	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	ICP - Integrated control panel	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	ICP - Integrated control panel	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	KVM - Keyless vehicle module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	KVM - Keyless vehicle module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	KVM - Keyless vehicle module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	KVM - Keyless vehicle module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PAM - Parking assist control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	PDM - Passenger's door module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	PDM - Passenger's door module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PDM - Passenger's door module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PDM - Passenger's door module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	PSM - Passenger's seat module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	PSM - Passenger's seat module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PSM - Passenger's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	PSM - Passenger's seat module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	HVAC - Heating ventilation and air conditioning control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	HVAC - Heating ventilation and air conditioning control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	HVAC - Heating ventilation and air conditioning control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	HVAC - Heating ventilation and air conditioning control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	RSB - Auxiliary junction box (body control module B)	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	RSB - Auxiliary junction box (body control module B)	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	RSB - Auxiliary junction box (body control module B)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	RSB - Auxiliary junction box (body control module B)	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	FCDIM - Front control/display interface module (high level display front)	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	FCDIM - Front control/display interface module (high level display front)	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	FCDIM - Front control/display interface module (high level display front)	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	FCDIM - Front control/display interface module (high level display front)	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	ACM - Audio front control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	ACM - Audio front control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	ACM - Audio front control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	ACM - Audio front control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	AAM - Audio amplifier module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	AAM - Audio amplifier module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	AAM - Audio amplifier module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	AAM - Audio amplifier module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	DABM - Digital audio broadcast module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	DABM - Digital audio broadcast module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	DABM - Digital audio broadcast module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	DABM - Digital audio broadcast module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	DACMC - Digital audio control module C	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	DACMC - Digital audio control module C	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	DACMC - Digital audio control module C	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	DACMC - Digital audio control module C	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	NCM - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	NCM - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	NCM - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	NCM - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	SRM - Satellite audio unit module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	SRM - Satellite audio unit module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	SRM - Satellite audio unit module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	SRM - Satellite audio unit module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	TEL - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	TEL - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	TEL - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	TEL - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	APIM - Accessory protocol interface module	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	APIM - Accessory protocol interface module	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	APIM - Accessory protocol interface module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	APIM - Accessory protocol interface module	Live Data		V1.00.001 or higher
Jaguar	XX	2010-2015	FLR - Forward looking radar	ECU Information		V1.00.001 or higher
Jaguar	XX	2010-2015	FLR - Forward looking radar	Read Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	FLR - Forward looking radar	Erase Codes		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Oil service counter reset		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Reset oil level		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Parking brake release to service position		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Tire pressure sensor replacement.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Tire pressure monitor confirmation application.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Tire pressure monitor receiver calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Tire pressure monitor sensor identification display		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Tire pressure monitoring tire pressure sensor test		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Battery replacement		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Brake bleed		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Program keys.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Erase all existing keys		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Verify keys		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Steering column calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Build mode		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Calibration learn		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Height calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Idle speed test.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Drivers side window calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Passenger side window calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Driver's seat calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Passenger's seat calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Seat cushion replacement		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Odometer calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Special functions	Headlamp and axle sensor calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Speed control alignment		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Idle speed test.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Purge valve self test		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Evaporative system diagnostic test		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Fuel prime routine		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Fuel lift pump		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Flight recorder.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	OBDDI readiness tests		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Powertrain control module adaption clear.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Transmission control module adaption clear		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Service history data		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	High pressure fuel pump test		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Fuel tank - Smoke test		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Brake bleed		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Control module calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Build mode		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Calibration learn		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Height calibration		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Program keys.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Erase all existing keys		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Verify keys		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Start authorisation status		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Driver's seat calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Passenger's seat calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Seat cushion replacement		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Headlamp and axle sensor calibration.		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Stepper motor initialisation		V1.00.001 or higher
Jaguar	XX	2010-2015	Service	Battery replacement		V1.00.001 or higher

Jaguar	XX	2003-2006	PSM - Passenger's seat module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	PSM - Passenger's seat module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PSM - Passenger's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PSM - Passenger's seat module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	PHM - Passenger's head restraint module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	PHM - Passenger's head restraint module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PHM - Passenger's head restraint module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PHM - Passenger's head restraint module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	DHM - Driver's head restraint module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	DHM - Driver's head restraint module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	DHM - Driver's head restraint module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	DHM - Driver's head restraint module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_L - Left lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_L - Left lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_L - Left lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_L - Left lighting control module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_R - Right lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_R - Right lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_R - Right lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADHLS_R - Right lighting control module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	ADRC - Adaptive damping ride control.	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	ADRC - Adaptive damping ride control.	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADRC - Adaptive damping ride control.	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ADRC - Adaptive damping ride control.	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	XX	2003-2006	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XX	2003-2006	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	XX	2003-2006		Special functions	Oil dilution reset	V1.00.001 or higher
Jaguar	XX	2003-2006		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	XX	2003-2006		Special functions	Program keys.	V1.00.001 or higher
Jaguar	XX	2003-2006		Special functions	Clear lost keyfob transmitters	V1.00.001 or higher
Jaguar	XX	2003-2006		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Parking brake release to service position	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Brake sensor set-up	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Alignment set-up	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	ABS control module configuration clear.	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Last alarm activations	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Clear lost keyfob transmitters	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Program new transponders	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Program keys.	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Right headlamp and/or left headlamp	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Oil dilution reset	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	XX	2003-2006		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	BCM - Body control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	BCM - Body control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	BCM - Body control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	BCM - Body control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ATCM - All terrain control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ATCM - All terrain control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ATCM - All terrain control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	ATCM - All terrain control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	CHCM - Chassis control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	CHCM - Chassis control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	CHCM - Chassis control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	CHCM - Chassis control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCM - Folding top control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCM - Folding top control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCM - Folding top control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCM - Folding top control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCMB - Folding top control module B	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCMB - Folding top control module B	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCMB - Folding top control module B	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	FTCMB - Folding top control module B	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GWMM - Gateway module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GWMM - Gateway module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GWMM - Gateway module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	GWMM - Gateway module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCM - Headlamp control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCM - Headlamp control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCM - Headlamp control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCM - Headlamp control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	OCS - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	OCS - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	OCS - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	OCS - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	PAM - Parking assist control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RDCM - Rear differential control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RDCM - Rear differential control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RDCM - Rear differential control module	Erase Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	RDCM - Rear differential control module	Live Data		V1.00.001 or higher
Jaguar	F-Type	2014-2015	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	F-Type	2014-2015	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	F-Type	2014-2015	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher

Jaguar	F-Type	2014-2015	VIM - Vehicle immobilizer control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	CAV - Connect and view module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	CAV - Connect and view module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	CAV - Connect and view module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	CAV - Connect and view module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCDIM - Front control/display interface module (high level display front)	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCDIM - Front control/display interface module (high level display front)	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCDIM - Front control/display interface module (high level display front)	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCDIM - Front control/display interface module (high level display front)	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCIM - Integrated control panel	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCIM - Integrated control panel	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCIM - Integrated control panel	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	FCIM - Integrated control panel	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCMCB - Headlamp control module B	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCMCB - Headlamp control module B	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCMCB - Headlamp control module B	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HCMCB - Headlamp control module B	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HVAC - Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HVAC - Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HVAC - Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	HVAC - Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPMB - Image processing module B	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPMB - Image processing module B	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPMB - Image processing module B	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	IPMB - Image processing module B	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PDM - Passenger's door module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PDM - Passenger's door module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PDM - Passenger's door module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PDM - Passenger's door module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PSM - Passenger's seat module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PSM - Passenger's seat module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PSM - Passenger's seat module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	PSM - Passenger's seat module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RFA - Keyless vehicle module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RFA - Keyless vehicle module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RFA - Keyless vehicle module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RFA - Keyless vehicle module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RGTM - Rear gate / trunk module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RGTM - Rear gate / trunk module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RGTM - Rear gate / trunk module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	RGTM - Rear gate / trunk module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODL - Side object detection control module - Left	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODL - Side object detection control module - Left	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODL - Side object detection control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	AAM - Audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	NCM - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	NCM - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	NCM - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	NCM - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2014-2015	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2014-2015	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Service interval reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Parking brake pad replacement - Release to service position	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Parking brake pad replacement - Exit maintenance mode application	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Parking brake activation	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Tire pressure sensor replacement	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Tire pressure sensor test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Battery replacement	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Test dual battery system	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Verify battery 2 charging	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Brake bleed	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Verify keys	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Check passive keys enabled	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Injector valve test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Steering angle sensor calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Variable assist power steering curves programming	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Height calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Petrol powertrain idle speed control test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Driver's seat calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Passenger's seat calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Petrol powertrain idle speed control test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Purge valve self test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Fuel prime routine	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Adaptive fuel trim display	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Powertrain control module adaption clear	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Injector valve test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Fuel pump supply - Enable/disable	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Engine control module unlock application	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Active exhaust system test	V1.00.001 or higher

Jaguar	F-Type	2014-2015	Service	Brake bleed	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Brake disc wear protection reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Brake disc wear protection level	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Control module calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Height calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Recover programmed keys	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Verify keys	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Check passive keys enabled	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Check all antennas	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Immobiliser antenna unit functionality check	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Start authorisation status	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Smart key health check	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Driver's seat calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Passenger's seat calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Actuator test	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Actuator initialisation	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Calibrate dynamic volume control	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Battery replacement	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Test dual battery system	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Verify battery 2 charging	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Quiescent current control module internal check	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Information and entertainment system special applications	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	DVD region counter reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Activate television test picture	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Valet mode reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Variable assist power steering curves programming.	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Transportation mode	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Restraints build mode	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Vehicle reset	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Odometer calibration	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Service	Alarm trigger history	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Front control/display interface module (high level display front)	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Folding top control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Auto high beam control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Front controls interface module (heating ventilation air conditioning)	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Immobiliser antenna unit	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	All terrain control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Image processing control module	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Power operated tailgate	V1.00.001 or higher
Jaguar	F-Type	2014-2015	Programming/Customization	Folding top control module B	V1.00.001 or higher
Jaguar	F-Type	2016 -	PCM - Powertrain control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	PCM - Powertrain control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	PCM - Powertrain control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	PCM - Powertrain control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCM - Transmission control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCM - Transmission control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCM - Transmission control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCM - Transmission control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	ABS - ABS control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	ABS - ABS control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	ABS - ABS control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	ABS - ABS control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	RCM - Restraints control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	RCM - Restraints control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	RCM - Restraints control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	RCM - Restraints control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	IPC - Instrument cluster control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	IPC - Instrument cluster control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	IPC - Instrument cluster control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	IPC - Instrument cluster control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	PBM - Parking brake control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	PBM - Parking brake control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	PBM - Parking brake control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	PBM - Parking brake control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	TPM - Tire pressure monitor module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	TPM - Tire pressure monitor module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TPM - Tire pressure monitor module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TPM - Tire pressure monitor module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	BCM - Body control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	BCM - Body control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	BCM - Body control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	BCM - Body control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	GSM - Gear shift module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	GSM - Gear shift module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	GSM - Gear shift module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	GSM - Gear shift module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	GWM - Gateway module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	GWM - Gateway module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	GWM - Gateway module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	GWM - Gateway module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	HCM - Headlamp control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	HCM - Headlamp control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	HCM - Headlamp control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	HCM - Headlamp control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	RDCM - Rear differential control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	RDCM - Rear differential control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	RDCM - Rear differential control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	RDCM - Rear differential control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCCM - Transfer case control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCCM - Transfer case control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCCM - Transfer case control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCCM - Transfer case control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCU - Telematic control unit module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCU - Telematic control unit module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCU - Telematic control unit module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	TCU - Telematic control unit module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	VIM - Vehicle immobilizer control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	VIM - Vehicle immobilizer control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	VIM - Vehicle immobilizer control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	VIM - Vehicle immobilizer control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	ATCM - All terrain control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	ATCM - All terrain control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	ATCM - All terrain control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	ATCM - All terrain control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	CHCM - Chassis control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	CHCM - Chassis control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	CHCM - Chassis control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	CHCM - Chassis control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCM - Folding top control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCM - Folding top control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCM - Folding top control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCM - Folding top control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCMB - Folding top control module B	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016 -	FTCMB - Folding top control module B	Read Codes	V1.00.001 or higher

Jaguar	F-Type	2016	FTCMB - Folding top control module B	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	FTCMB - Folding top control module B	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	IPMA - Image processing control module A	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	IPMA - Image processing control module A	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	IPMA - Image processing control module A	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	IPMA - Image processing control module A	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	OCS - Restraints occupant classification system module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	OCS - Restraints occupant classification system module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	OCS - Restraints occupant classification system module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	OCS - Restraints occupant classification system module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	PAM - Parking assist control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	PAM - Parking assist control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PAM - Parking assist control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PAM - Parking assist control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	PSCM - Power steering control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	PSCM - Power steering control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PSCM - Power steering control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PSCM - Power steering control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	SASM - Steering angle sensor module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	SASM - Steering angle sensor module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SASM - Steering angle sensor module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SASM - Steering angle sensor module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	PDM - Passenger's door module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	PDM - Passenger's door module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PDM - Passenger's door module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PDM - Passenger's door module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	PSM - Passenger's seat module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	PSM - Passenger's seat module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PSM - Passenger's seat module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	PSM - Passenger's seat module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	RFA - Keyless vehicle module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	RFA - Keyless vehicle module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	RFA - Keyless vehicle module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	RFA - Keyless vehicle module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	RGTM - Rear gate / trunk module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	RGTM - Rear gate / trunk module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	RGTM - Rear gate / trunk module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	RGTM - Rear gate / trunk module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	AHU - InControl Touch audio head unit	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	AHU - InControl Touch audio head unit	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	AHU - InControl Touch audio head unit	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	AHU - InControl Touch audio head unit	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	CAV - Connect and view module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	CAV - Connect and view module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	CAV - Connect and view module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	CAV - Connect and view module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	FCDIM - Front control/display interface module (high level display front)	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	FCDIM - Front control/display interface module (high level display front)	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	FCDIM - Front control/display interface module (high level display front)	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	FCDIM - Front control/display interface module (high level display front)	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	FCIM - Integrated control panel	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	FCIM - Integrated control panel	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	FCIM - Integrated control panel	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	FCIM - Integrated control panel	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	HVAC - Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	HVAC - Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	HVAC - Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	HVAC - Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	IPMB - Image processing module B	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	IPMB - Image processing module B	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	IPMB - Image processing module B	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	IPMB - Image processing module B	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	NAV - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	NAV - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	NAV - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	NAV - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	SODL - Side object detection control module - Left	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	SODL - Side object detection control module - Left	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SODL - Side object detection control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	AAM - Audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	NCM - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	NCM - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	NCM - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	NCM - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	F-Type	2016	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	F-Type	2016	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	F-Type	2016	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	F-Type	2016		Special functions	Service interval reset.
Jaguar	F-Type	2016		Special functions	Oil change reset
Jaguar	F-Type	2016		Special functions	Oil service counter reset
Jaguar	F-Type	2016		Special functions	Parking brake pad replacement - Release to service position
Jaguar	F-Type	2016		Special functions	Parking brake pad replacement - Exit maintenance mode application
Jaguar	F-Type	2016		Special functions	Parking brake activation
Jaguar	F-Type	2016		Special functions	Tire pressure sensor replacement.
Jaguar	F-Type	2016		Special functions	Tire pressure monitor sensor identification display
Jaguar	F-Type	2016		Special functions	Steering column calibration
Jaguar	F-Type	2016		Special functions	Power steering soft-lock end stops reset routine
Jaguar	F-Type	2016		Special functions	Lock steering tune to vehicle
Jaguar	F-Type	2016		Special functions	Telematics control module battery replacement reset
Jaguar	F-Type	2016		Special functions	Test internal backup battery
Jaguar	F-Type	2016		Special functions	Battery replacement
Jaguar	F-Type	2016		Special functions	Idle speed test.
Jaguar	F-Type	2016		Special functions	Throttle valve actuator replacement
Jaguar	F-Type	2016		Special functions	Injector valve test
Jaguar	F-Type	2016		Special functions	Headlamp control module system calibration
Jaguar	F-Type	2016		Special functions	Driver's seat calibration.
Jaguar	F-Type	2016		Special functions	Passenger's seat calibration.
Jaguar	F-Type	2016		Special functions	Seat cushion replacement

Jaguar	F-Type	2016 -		Special functions	Driver's side - Door glass window calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Special functions	Passenger's side - Door glass window calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Idle speed test.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Injector valve test	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Test internal backup battery	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Driver's side - Door glass window calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Passenger's side - Door glass window calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Service interval reset.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Steering column calibration	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Vehicle reset	V1.00.001 or higher
Jaguar	F-Type	2016 -		Service	Battery replacement	V1.00.001 or higher
Jaguar	S-Type	2004-2005	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AHCM - Auxiliary heater control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AHCM - Auxiliary heater control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AHCM - Auxiliary heater control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AHCM - Auxiliary heater control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ACC - Adaptive speed control control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ACC - Adaptive speed control control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ACC - Adaptive speed control control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ACC - Adaptive speed control control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADRC - Adaptive damping ride control.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADRC - Adaptive damping ride control.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADRC - Adaptive damping ride control.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADRC - Adaptive damping ride control.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	FETM - Audio unit.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	FETM - Audio unit.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	FETM - Audio unit.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	FETM - Audio unit.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	GEM - General electronics control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	GEM - General electronics control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	GEM - General electronics control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	GEM - General electronics control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	REM - Rear electronic control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	REM - Rear electronic control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	REM - Rear electronic control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	REM - Rear electronic control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	SCLM - Steering column lock module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	SCLM - Steering column lock module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	SCLM - Steering column lock module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	SCLM - Steering column lock module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADHLS - Headlamp levelling system.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADHLS - Headlamp levelling system.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADHLS - Headlamp levelling system.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ADHLS - Headlamp levelling system.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2004-2005	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2004-2005	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Oil dilution reset	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Program keys.	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Special functions	Seat calibration	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Parking brake release to service position	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Brake sensor set-up	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	ABS control module configuration clear.	V1.00.001 or higher

Jaguar	S-Type	2004-2005		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Last alarm activations	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Program new transponders	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Program keys.	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Program additional transponders	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Seat calibration	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Steering column calibration	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Oil dilution reset	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Fuel burn heater - operation check	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Fuel burning heater, fuel priming routine.	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	S-Type	2004-2005		Service	Vehicle control module identification	V1.00.001 or higher
Jaguar	S-Type	2006-2008	PCM - Powertrain control module	ECU Information	Evaporative system leak check	V1.00.001 or higher
Jaguar	S-Type	2006-2008	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ACC - Adaptive speed control control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ACC - Adaptive speed control control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ACC - Adaptive speed control control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ACC - Adaptive speed control control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADRC - Adaptive damping ride control.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADRC - Adaptive damping ride control.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADRC - Adaptive damping ride control.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADRC - Adaptive damping ride control.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	FETM - Audio unit.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	FETM - Audio unit.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	FETM - Audio unit.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	FETM - Audio unit.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	GEM - General electronics control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	GEM - General electronics control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	GEM - General electronics control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	GEM - General electronics control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	REM - Rear electronic control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	REM - Rear electronic control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	REM - Rear electronic control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	REM - Rear electronic control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	SCLM - Steering column lock module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	SCLM - Steering column lock module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	SCLM - Steering column lock module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	SCLM - Steering column lock module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADHLS - Headlamp levelling system.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADHLS - Headlamp levelling system.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADHLS - Headlamp levelling system.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ADHLS - Headlamp levelling system.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	S-Type	2006-2008	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	S-Type	2006-2008	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Particle filter regeneration	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Program keys.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Lateral accelerometer calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Pressure sensor calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Powertrain configuration reset.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Special functions	Seat calibration	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Parking brake release to service position	V1.00.001 or higher

Jaguar	S-Type	2006-2008		Service	Lateral accelerometer calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Pressure sensor calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Powertrain configuration reset.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Program additional transponders	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Last alarm activations	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Program keys.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Program new transponders	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Steering column calibration	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Seat calibration	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Right headlamp and/or left headlamp	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Fuel burn heater - operation check	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Fuel burning heater, fuel priming routine.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Fuel prime routine.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Vehicle control module identification	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Idle speed test.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Petrol engine control module adaption clear	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Purge valve self test	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	S-Type	2006-2008		Service	Particle filter regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ADCM - Adaptive damping control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ADCM - Adaptive damping control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ADCM - Adaptive damping control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ADCM - Adaptive damping control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HCM - Headlamp control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HCM - Headlamp control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HCM - Headlamp control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HCM - Headlamp control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICS - Impact classification system	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICS - Impact classification system	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICS - Impact classification system	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICS - Impact classification system	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	OCS - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	OCS - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	OCS - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	OCS - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	VIM - Vehicle immobilizer control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DCSM - Driver's climate seat module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DCSM - Driver's climate seat module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DCSM - Driver's climate seat module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DCSM - Driver's climate seat module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FSJB - Central junction box (body control module)	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FSJB - Central junction box (body control module)	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FSJB - Central junction box (body control module)	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FSJB - Central junction box (body control module)	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HVAC - Heating ventilation and air conditioning control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HVAC - Heating ventilation and air conditioning control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HVAC - Heating ventilation and air conditioning control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	HVAC - Heating ventilation and air conditioning control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICM - Infotainment control module.	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICM - Infotainment control module.	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICM - Infotainment control module.	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICM - Infotainment control module.	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICP - Integrated control panel	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICP - Integrated control panel	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ICP - Integrated control panel	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	KVM - Keyless vehicle module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	KVM - Keyless vehicle module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	KVM - Keyless vehicle module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	KVM - Keyless vehicle module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PAM - Parking assist control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PDM - Passenger's door module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PDM - Passenger's door module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PDM - Passenger's door module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	PDM - Passenger's door module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RSJB - Auxiliary junction box (body control module B)	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RSJB - Auxiliary junction box (body control module B)	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RSJB - Auxiliary junction box (body control module B)	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	RSJB - Auxiliary junction box (body control module B)	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODL - Side object detection control module - Left	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODL - Side object detection control module - Left	Read Codes		V1.00.001 or higher

Jaguar	Jaguar XF	2008-2009	SODL - Side object detection control module - Left	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODL - Side object detection control module - Left	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODR - Side object detection control module - Right	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODR - Side object detection control module - Right	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODR - Side object detection control module - Right	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SODR - Side object detection control module - Right	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FCDIM - Front control/display interface module (high level display front)	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FCDIM - Front control/display interface module (high level display front)	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FCDIM - Front control/display interface module (high level display front)	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FCDIM - Front control/display interface module (high level display front)	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ACM - Audio front control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ACM - Audio front control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ACM - Audio front control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	ACM - Audio front control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	AAM - Audio amplifier module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	AAM - Audio amplifier module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	AAM - Audio amplifier module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	AAM - Audio amplifier module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	APIM - Accessory protocol interface module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	APIM - Accessory protocol interface module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	APIM - Accessory protocol interface module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	APIM - Accessory protocol interface module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	NCM - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	NCM - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	NCM - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	NCM - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SRM - Satellite audio unit module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SRM - Satellite audio unit module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SRM - Satellite audio unit module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	SRM - Satellite audio unit module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TEL - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TEL - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TEL - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TEL - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TVM - Television module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TVM - Television module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TVM - Television module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	TVM - Television module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DABM - Digital audio broadcast module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DABM - Digital audio broadcast module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DABM - Digital audio broadcast module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	DABM - Digital audio broadcast module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FLR - Forward looking radar	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FLR - Forward looking radar	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	FLR - Forward looking radar	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Reset the oil service counter.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Parking brake release to service position		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Tire pressure sensor replacement.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Tire pressure monitor confirmation application.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Tire pressure monitor receiver calibration.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Tire pressure monitoring tire pressure sensor test		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Battery replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Brake bleed		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Diesel particulate filter dynamic regeneration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Diesel particulate filter replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Diesel particulate filter condition (stored values)		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Diesel particulate filter fuel related component replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Program keys.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Erase all existing keys		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Verify keys		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Steering column calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Calibration learn		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Idle speed test.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Drivers side window calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Passenger side window calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Driver's seat calibration.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Seat cushion replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Odometer calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Special functions	Headlamp control module system calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Speed control alignment		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Speed control internal state		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Idle speed test.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Purge valve self test		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Evaporative system leak check		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Fuel prime routine		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Flight recorder.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	OBDDI readiness tests		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Powertrain control module adaption clear.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Transmission control module adaption clear		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Air conditioning system adaption reset		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	High pressure injection pump replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Brake bleed		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Calibration learn		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Program keys.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Erase all existing keys		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Verify keys		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Start authorisation status		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Driver's seat calibration.		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Seat cushion replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Headlamp control module system calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Vent actuators test		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Stepper motor initialisation		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Battery replacement		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Side object detection module history		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Right side - Radar signal - Reversal correction		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Drivers side window calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Passenger side window calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Pedestrian impact crash status reset		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Restraints build mode		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Service	Odometer calibration		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	ABS control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Adaptive damping control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Front control/display interface module (high level display front)		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Navigation control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Parking assist control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Parking brake control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Side object detection control module - Left		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Speed control module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Tire pressure monitor module		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Vehicle immobilizer control module (steering column lock)		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Central junction box configuration update		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Mirror personalisation features		V1.00.001 or higher
Jaguar	Jaguar XF	2008-2009	Programming/Customization	Passenger restraint disable switch		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	RCM - Restraints control module	Read Codes		V1.00.001 or higher

Jaguar	Jaguar XF	2010-2011	TEL - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TEL - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TVM - Television module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TVM - Television module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TVM - Television module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	TVM - Television module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	DABM - Digital audio broadcast module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	DABM - Digital audio broadcast module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	DABM - Digital audio broadcast module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	DABM - Digital audio broadcast module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	FLR - Forward looking radar	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	FLR - Forward looking radar	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011	FLR - Forward looking radar	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Rest of world - Service interval options	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Reset oil level	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Tire pressure monitoring tire pressure sensor test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Program keys.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Erase all existing keys	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Driver's seat calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Speed control alignment	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Reset water in fuel detection	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Turbine shut-off valve	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Exhaust gas recirculation valve	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Oxygen sensor	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Oxidation catalyst	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Purge valve self test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Fuel prime routine	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Fuel lift pump	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Flight recorder.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Service history data	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Paddle shift configuration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Air path set-up routine.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Control module calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Program keys.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Erase all existing keys	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Start authorisation status	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Vent actuators test	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Stepper motor initialisation	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Side object detection module history	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Side object detection configuration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Pedestrian impact crash status reset	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Restraints build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Service	Alarm trigger history	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Active damping control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Digital audio broadcast module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Front control/display interface module (high level display front)	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Side object detection control module - Left	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Tire pressure monitor module	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Vehicle immobilizer control module (steering column lock)	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Mirror personalisation features	V1.00.001 or higher
Jaguar	Jaguar XF	2010-2011		Programming/Customization	Passenger restraint disable switch	V1.00.001 or higher
Jaguar	Jaguar XF	2012	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2012	PBM - Parking brake control module	Live Data		V1.00.001 or higher

Jaguar	Jaguar XF	2012	TVM - Television module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Rest of world - Service interval options	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Reset oil level	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Tire pressure monitoring tire pressure sensor test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Erase all existing keys	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	idle speed - Adjustment	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Special functions	Change tire size	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Speed control alignment	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Reset water in fuel detection	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Turbine shut-off valve	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Exhaust gas recirculation valve	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Oxygen sensor	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Oxidation catalyst	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Diesel fueling adaption re-initialization	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Purge valve self test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Fuel prime routine	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Fuel lift pump	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Flight recorder.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	OBDDI readiness tests	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Service history data	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	idle speed - Adjustment	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Air path set-up routine	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Control module calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Erase all existing keys	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Start authorisation status	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Vent actuators test	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Stepper motor initialisation	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Calibrate dynamic volume control	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Side object detection module history	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Side object detection configuration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Information and entertainment system special applications	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Navigation reset	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	DVD region counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Clear module learn data	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Restraints build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Service	Alarm trigger history	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Active damping control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Digital audio broadcast module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Auto high beam control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Front controls interface module 'B' (front audio control panel)	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Side object detection control module - Left	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Tire pressure monitor module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Vehicle immobilizer control module (steering column lock)	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Gateway module	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Right side safety belt pretensioner	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Left side safety belt pretensioner	V1.00.001 or higher
Jaguar	Jaguar XF	2012		Programming/Customization	Change tire size	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	PBM - Parking brake control module	Read Codes		V1.00.001 or higher

Jaguar	Jaguar XF	2013-2015	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	NCM - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	NCM - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	NCM - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	NCM - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Rest of world - Service interval options	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Oil change reset	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Tire pressure monitoring tire pressure sensor test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Test dual battery system	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Verify battery 2 charging	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Check passive keys enabled	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Injector valve test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Air suspension deflation.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Suspension Enable	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Suspension geometry set-up	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Petrol powertrain idle speed control test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Idle speed - Adjustment	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Speed control alignment	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Calibrate clutch	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Transfer case classification	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Oil change reset	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Reset water in fuel detection	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Turbine shut-off valve	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Exhaust gas recirculation valve	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Oxygen sensor	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Oxidation catalyst	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Diesel fuelling adaption re-initialization	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Petrol powertrain idle speed control test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Purge valve self test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Fuel prime routine	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Fuel lift pump	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Adaptive fuel trim display	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Idle speed - Adjustment	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Injector valve test	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Fuel pump supply - Enable/disable	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Engine control module unlock application	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Air path set-up routine	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Brake bleed	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Control module calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Air suspension deflation.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Suspension Enable	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Suspension geometry set-up	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Calibration learn	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Height calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Recover programmed keys	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Verify keys	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Check passive keys enabled	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Check all antennas	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Start authorisation status	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Vent actuators test	V1.00.001 or higher

Jaguar	Jaguar XF	2013-2015	Service	Stepper motor initialisation	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Auxiliary heater priming routine	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Auxiliary heater operation check.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Calibrate dynamic volume control	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Test dual battery system	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Verify battery 2 charging	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Quiescent current control module internal check	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Side object detection configuration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Information and entertainment system special applications	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Navigation reset	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	DVD region counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Activate television test picture	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Clear module learn data	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Transportation mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Restraints build mode	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Odometer calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Service	Alarm trigger history	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Active damping control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Front control/display interface module (high level display front)	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Auto high beam control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Remote climate control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Front controls interface module 'B' (front audio control panel)	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Tire pressure monitor module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Immobiliser antenna unit	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Gateway module	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Power operated tailgate	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Right side safety belt pretensioner	V1.00.001 or higher
Jaguar	Jaguar XF	2013-2015	Programming/Customization	Left side safety belt pretensioner	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PCM - Powertrain control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PCM - Powertrain control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PCM - Powertrain control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PCM - Powertrain control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transmission control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transmission control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transmission control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transmission control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ABS - ABS control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ABS - ABS control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ABS - ABS control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ABS - ABS control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	RCM - Restraints control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	RCM - Restraints control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	RCM - Restraints control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	RCM - Restraints control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	IPC - Instrument cluster control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	IPC - Instrument cluster control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	IPC - Instrument cluster control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	IPC - Instrument cluster control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TPM - Tire pressure monitor module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TPM - Tire pressure monitor module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TPM - Tire pressure monitor module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TPM - Tire pressure monitor module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	BCM - Body control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	BCM - Body control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	BCM - Body control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	BCM - Body control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CCM - Speed control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CCM - Speed control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CCM - Speed control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CCM - Speed control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GSM - Gear shift module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GSM - Gear shift module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GSM - Gear shift module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GSM - Gear shift module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GWM - Gateway module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GWM - Gateway module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GWM - Gateway module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	GWM - Gateway module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	OCS - Restraints occupant classification system module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	OCS - Restraints occupant classification system module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	OCS - Restraints occupant classification system module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	OCS - Restraints occupant classification system module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transfer case control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transfer case control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transfer case control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCM - Transfer case control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCU - Telematic control unit module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCU - Telematic control unit module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCU - Telematic control unit module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	TCU - Telematic control unit module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	VIM - Vehicle immobilizer control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	VIM - Vehicle immobilizer control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	VIM - Vehicle immobilizer control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	VIM - Vehicle immobilizer control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ATCM - All terrain control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ATCM - All terrain control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ATCM - All terrain control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	ATCM - All terrain control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CHCM - Chassis control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CHCM - Chassis control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CHCM - Chassis control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	CHCM - Chassis control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PAM - Parking assist control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PAM - Parking assist control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PAM - Parking assist control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PAM - Parking assist control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PSCM - Power steering control module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PSCM - Power steering control module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PSCM - Power steering control module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	PSCM - Power steering control module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	SASM - Steering angle sensor module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	SASM - Steering angle sensor module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	SASM - Steering angle sensor module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	SASM - Steering angle sensor module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AHU - InControl Touch audio head unit	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AHU - InControl Touch audio head unit	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AHU - InControl Touch audio head unit	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AHU - InControl Touch audio head unit	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AUCM - Head-up display cooling fan module	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AUCM - Head-up display cooling fan module	Read Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AUCM - Head-up display cooling fan module	Erase Codes	V1.00.001 or higher
Jaguar	Jaguar XF	2016	AUCM - Head-up display cooling fan module	Live Data	V1.00.001 or higher
Jaguar	Jaguar XF	2016	FCIM - Integrated control panel	ECU Information	V1.00.001 or higher
Jaguar	Jaguar XF	2016	FCIM - Integrated control panel	Read Codes	V1.00.001 or higher

Jaguar	Jaguar XF	2016 -	FCIM - Integrated control panel	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	FCIM - Integrated control panel	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HUD - Head up display	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HUD - Head up display	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HUD - Head up display	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HUD - Head up display	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HVAC - Heating ventilation and air conditioning control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HVAC - Heating ventilation and air conditioning control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HVAC - Heating ventilation and air conditioning control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	HVAC - Heating ventilation and air conditioning control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IMC - InControl Touch Pro infotainment master controller	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IMC - InControl Touch Pro infotainment master controller	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IMC - InControl Touch Pro infotainment master controller	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IMC - InControl Touch Pro infotainment master controller	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMA - Image processing control module A	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMA - Image processing control module A	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMA - Image processing control module A	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMA - Image processing control module A	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMB - Image processing module B	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMB - Image processing module B	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMB - Image processing module B	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	IPMB - Image processing module B	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODL - Side object detection control module - Left	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODL - Side object detection control module - Left	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODL - Side object detection control module - Left	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODL - Side object detection control module - Left	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODR - Side object detection control module - Right	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODR - Side object detection control module - Right	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODR - Side object detection control module - Right	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	SODR - Side object detection control module - Right	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DRDM - Driver's (side) rear door module.	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DRDM - Driver's (side) rear door module.	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DRDM - Driver's (side) rear door module.	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DRDM - Driver's (side) rear door module.	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PDM - Passenger's door module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PDM - Passenger's door module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PDM - Passenger's door module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PDM - Passenger's door module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PRDM - Passenger's (side) rear door module.	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PRDM - Passenger's (side) rear door module.	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PRDM - Passenger's (side) rear door module.	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PRDM - Passenger's (side) rear door module.	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PSM - Passenger's seat module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PSM - Passenger's seat module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PSM - Passenger's seat module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	PSM - Passenger's seat module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RFA - Keyless vehicle module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RFA - Keyless vehicle module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RFA - Keyless vehicle module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RFA - Keyless vehicle module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RGTM - Rear gate / trunk module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RGTM - Rear gate / trunk module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RGTM - Rear gate / trunk module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	RGTM - Rear gate / trunk module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	TBM - Deployable towbar control module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	TBM - Deployable towbar control module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	TBM - Deployable towbar control module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	TBM - Deployable towbar control module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	AAM - InControl Touch Pro audio amplifier module	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	AAM - InControl Touch Pro audio amplifier module	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	AAM - InControl Touch Pro audio amplifier module	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	AAM - InControl Touch Pro audio amplifier module	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	ISC - InControl Touch Pro infotainment slave controller	ECU Information		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	ISC - InControl Touch Pro infotainment slave controller	Read Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	ISC - InControl Touch Pro infotainment slave controller	Erase Codes		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -	ISC - InControl Touch Pro infotainment slave controller	Live Data		V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Parking brake pad replacement - Release to service position	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Parking brake pad replacement - Exit maintenance mode application	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Parking brake activation	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Apply and release electric park brake	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Test internal backup battery	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Battery replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Injector valve test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Automatic high beam camera calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Passengers seat massage on demand self test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Roof blind calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Sunroof calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Special functions	Door window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Speed control alignment	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Injector replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Idle speed test.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Injector valve test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Passengers seat massage on demand self test	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Automatic high beam camera calibration	V1.00.001 or higher

Jaguar	Jaguar XF	2016 -		Service	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Test internal backup battery	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Roof Blind calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Steering column calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Sunroof calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Door window calibration	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Service interval reset.	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Vehicle reset	V1.00.001 or higher
Jaguar	Jaguar XF	2016 -		Service	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2002-2005	ECM - Engine control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ECM - Engine control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ECM - Engine control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ECM - Engine control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	EPB - Electronic parking brake	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	EPB - Electronic parking brake	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	EPB - Electronic parking brake	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	EPB - Electronic parking brake	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ACC - Adaptive speed control control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ACC - Adaptive speed control control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ACC - Adaptive speed control control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ACC - Adaptive speed control control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ASU - Air suspension module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ASU - Air suspension module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ASU - Air suspension module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ASU - Air suspension module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	RATC - Rear climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	RATC - Rear climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RATC - Rear climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RATC - Rear climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	GEM - General electronics control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	GEM - General electronics control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	GEM - General electronics control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	GEM - General electronics control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	REM - Rear electronic control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	REM - Rear electronic control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	REM - Rear electronic control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	REM - Rear electronic control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	RSM - Rear seat control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	RSM - Rear seat control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RSM - Rear seat control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RSM - Rear seat control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	SCLM - Steering column lock module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	SCLM - Steering column lock module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	SCLM - Steering column lock module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	SCLM - Steering column lock module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	FETM - Audio unit	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	FETM - Audio unit	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	FETM - Audio unit	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	FETM - Audio unit	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_L - Left lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_L - Left lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_L - Left lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_R - Right lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_R - Right lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ADHLS_R - Right lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	RETm - Rear entertainment control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	RETm - Rear entertainment control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RETm - Rear entertainment control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	RETm - Rear entertainment control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2002-2005	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2002-2005	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Oil dilution reset		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Parking brake release to service position		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Program keys.		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Immobilization set-up		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Steering column calibration		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Seat cushion replacement		V1.00.001 or higher
Jaguar	XI range	2002-2005	Special functions	Seat calibration		V1.00.001 or higher
Jaguar	XI range	2002-2005	Service	Parking brake release to service position		V1.00.001 or higher
Jaguar	XI range	2002-2005	Service	Brake sensor set-up		V1.00.001 or higher
Jaguar	XI range	2002-2005	Service	ABS control module configuration clear.		V1.00.001 or higher

Jaguar	XI range	2002-2005		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Seat calibration	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Program new transponders	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Program additional transponders	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Last alarm activations	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Program keys.	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Right headlamp and/or left headlamp	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Oil dilution reset	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	XI range	2002-2005		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	XI range	2006-2007	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	AHCM - Auxiliary heater control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	AHCM - Auxiliary heater control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	AHCM - Auxiliary heater control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	AHCM - Auxiliary heater control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ACC - Adaptive speed control control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ACC - Adaptive speed control control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ACC - Adaptive speed control control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ACC - Adaptive speed control control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ASU - Air suspension module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ASU - Air suspension module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ASU - Air suspension module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ASU - Air suspension module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	RATC - Rear climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	RATC - Rear climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RATC - Rear climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RATC - Rear climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	FETM - Audio unit	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	FETM - Audio unit	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	FETM - Audio unit	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	FETM - Audio unit	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	GEM - General electronics control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	GEM - General electronics control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	GEM - General electronics control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	GEM - General electronics control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	REM - Rear electronic control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	REM - Rear electronic control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	REM - Rear electronic control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	REM - Rear electronic control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	RSM - Rear seat control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	RSM - Rear seat control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RSM - Rear seat control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RSM - Rear seat control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	SCLM - Steering column lock module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	SCLM - Steering column lock module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	SCLM - Steering column lock module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	SCLM - Steering column lock module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_L - Left lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_L - Left lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_L - Left lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_R - Right lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_R - Right lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ADHLS_R - Right lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	RETM - Rear entertainment control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	RETM - Rear entertainment control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RETM - Rear entertainment control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	RETM - Rear entertainment control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2006-2007	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2006-2007	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Tire pressure monitor confirmation application.	V1.00.001 or higher

Jaguar	XI range	2006-2007		Special functions	Particle filter regeneration	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Program keys.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Air suspension transportation/customer mode.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Air suspension transportation/customer mode.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Program additional transponders	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Last alarm activations	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Program new transponders	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Program keys.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Right headlamp and/or left headlamp	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Fuel burn heater - operation check	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Engine control module data recorder	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Fuel prime routine.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Engine fuel priming routine.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Petrol engine control module adaption clear	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Purge valve self test	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Fuel burn heater - fuel prime application	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	XI range	2006-2007		Service	Particle filter regeneration	V1.00.001 or higher
Jaguar	XI range	2008-2009	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	AHCM - Auxiliary heater control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	AHCM - Auxiliary heater control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	AHCM - Auxiliary heater control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	AHCM - Auxiliary heater control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	DCSM - Driver's climate seat module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	DCSM - Driver's climate seat module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DCSM - Driver's climate seat module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DCSM - Driver's climate seat module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ACC - Adaptive speed control control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ACC - Adaptive speed control control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ACC - Adaptive speed control control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ACC - Adaptive speed control control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ASU - Air suspension module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ASU - Air suspension module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ASU - Air suspension module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ASU - Air suspension module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	RATC - Rear climate control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	RATC - Rear climate control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RATC - Rear climate control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RATC - Rear climate control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	DDM - Driver's door module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	DDM - Driver's door module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DDM - Driver's door module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DDM - Driver's door module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	DSM - Driver's seat module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	DSM - Driver's seat module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DSM - Driver's seat module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	DSM - Driver's seat module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	FETM - Audio unit	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	FETM - Audio unit	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	FETM - Audio unit	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	FETM - Audio unit	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	GEM - General electronics control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	GEM - General electronics control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	GEM - General electronics control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	GEM - General electronics control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	REM - Rear electronic control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	REM - Rear electronic control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	REM - Rear electronic control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	REM - Rear electronic control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	RSM - Rear seat control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	RSM - Rear seat control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RSM - Rear seat control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RSM - Rear seat control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	SCLM - Steering column lock module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	SCLM - Steering column lock module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	SCLM - Steering column lock module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	SCLM - Steering column lock module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_L - Left lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_L - Left lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_L - Left lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_R - Right lighting control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_R - Right lighting control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ADHLS_R - Right lighting control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher

Jaguar	XI range	2008-2009	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	GWM - Gateway module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	GWM - Gateway module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	GWM - Gateway module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	GWM - Gateway module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	RETM - Rear entertainment control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	RETM - Rear entertainment control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RETM - Rear entertainment control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	RETM - Rear entertainment control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	XI range	2008-2009	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2008-2009	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Program keys.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Lateral accelerometer calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Pressure sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Powertrain configuration reset.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Air suspension transportation/customer mode.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2008-2009		Special functions	Seat calibration	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Lateral accelerometer calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Pressure sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Powertrain configuration reset.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Air suspension transportation/customer mode.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Seat calibration	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Program additional transponders	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Last alarm activations	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Program new transponders	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Program keys.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Right headlamp and/or left headlamp	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Fuel burn heater - operation check	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Engine control module data recorder	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Fuel prime routine.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Fuel burn heater - fuel prime application	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Purge valve self test	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Petrol engine control module adaption clear	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Engine fuel priming routine.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	XI range	2008-2009		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2010-2012	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	BCM - Body control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	BCM - Body control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	BCM - Body control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	BCM - Body control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	HCM - Headlamp control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	HCM - Headlamp control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	HCM - Headlamp control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	HCM - Headlamp control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	OCS - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	OCS - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	OCS - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	OCS - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCM - Rear differential control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCM - Rear differential control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCM - Rear differential control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCM - Rear differential control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	RLM - Ride level control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	RLM - Ride level control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RLM - Ride level control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2010-2012	RLM - Ride level control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMA - Safety belt pretensioner control module A - drivers side	ECU Information		V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMA - Safety belt pretensioner control module A - drivers side	Read Codes		V1.00.001 or higher

Jaguar	XI range	2010-2012	SPMA - Safety belt pretensioner control module A - drivers side	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMA - Safety belt pretensioner control module A - drivers side	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMB - Safety belt pretensioner control module B - passengers side	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMB - Safety belt pretensioner control module B - passengers side	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMB - Safety belt pretensioner control module B - passengers side	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SPMB - Safety belt pretensioner control module B - passengers side	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	SUMB - Adaptive damping control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	SUMB - Adaptive damping control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SUMB - Adaptive damping control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SUMB - Adaptive damping control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	VIM - Vehicle immobilizer control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	VIM - Vehicle immobilizer control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	VIM - Vehicle immobilizer control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	VIM - Vehicle immobilizer control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	DCSM - Driver's climate seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	DCSM - Driver's climate seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DCSM - Driver's climate seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DCSM - Driver's climate seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCDIM - Front control/display interface module (high level display front)	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCDIM - Front control/display interface module (high level display front)	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCDIM - Front control/display interface module (high level display front)	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCDIM - Front control/display interface module (high level display front)	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCIMB - Front controls interface module 'B' (front audio control panel)	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCIMB - Front controls interface module 'B' (front audio control panel)	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCIMB - Front controls interface module 'B' (front audio control panel)	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	FCIMB - Front controls interface module 'B' (front audio control panel)	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	HCMB - Headlamp control module 'B'	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	HCMB - Headlamp control module 'B'	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	HCMB - Headlamp control module 'B'	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	HCMB - Headlamp control module 'B'	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	HVAC - Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	HVAC - Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	HVAC - Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	HVAC - Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	KVM - Keyless vehicle module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	KVM - Keyless vehicle module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	KVM - Keyless vehicle module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	KVM - Keyless vehicle module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	PAM - Parking assist control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	PAM - Parking assist control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PAM - Parking assist control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PAM - Parking assist control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	PDM - Passenger's door module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	PDM - Passenger's door module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PDM - Passenger's door module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PDM - Passenger's door module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	PSM - Passenger's seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	PSM - Passenger's seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PSM - Passenger's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	PSM - Passenger's seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCSM - Rear climate seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCSM - Rear climate seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCSM - Rear climate seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RDCSM - Rear climate seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	RGTM - Rear gate / trunk module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	RGTM - Rear gate / trunk module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RGTM - Rear gate / trunk module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RGTM - Rear gate / trunk module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	RHVAC - Rear Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	RHVAC - Rear Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RHVAC - Rear Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	RHVAC - Rear Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODL - Side object detection control module - Left	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODL - Side object detection control module - Left	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODL - Side object detection control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	AAM - Audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	REM - Rear entertainment control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	REM - Rear entertainment control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	REM - Rear entertainment control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	REM - Rear entertainment control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2010-2012	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2010-2012	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Rest of world - Service interval options	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Tire pressure sensor test	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Brake bleed	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Add additional keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Replace faulty/lost keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Add additional keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Replace faulty/lost keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Verify keys	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Check passive keys enabled	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Variable assist power steering curves programming.	V1.00.001 or higher
Jaguar	XI range	2010-2012	Special functions	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher

Jaguar	XI range	2010-2012		Special functions	Height calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Air suspension deflation.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Suspension Enable	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Suspension geometry set-up	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Suspension tight tolerance control	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Build mode	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Calibration learn	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Sunroof calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2010-2012		Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Speed control alignment	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Reset water in fuel detection	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Turbine shut-off valve	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Exhaust gas recirculation valve	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Oxygen sensor	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Oxidation catalyst	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Purge valve self test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Fuel prime routine	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Fuel lift pump	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Flight recorder.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	OBDII readiness tests	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Service history data	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Paddle shift configuration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Air path set-up routine	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Brake bleed	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Control module calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Height calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Air suspension deflation.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Suspension Enable	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Suspension geometry set-up	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Suspension tight tolerance control	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Build mode	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Calibration learn	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Add additional keys	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Replace faulty/lost keys	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Verify keys	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Check passive keys enabled	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Check all antennas	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Start authorisation status	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Actuator test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Actuator initialisation	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Evaporator and heater test	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Calibrate dynamic volume control	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Side object detection module history	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Navigation reset	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	DVD region counter reset	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Dynamic seat belt retract and release	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Clear module learn data	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Sunroof calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Valet mode reset	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Variable assist power steering curves programming.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Transportation mode	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Restraints build mode	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Vehicle reset	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Odometer calibration	V1.00.001 or higher
Jaguar	XI range	2010-2012		Service	Alarm trigger history	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Digital audio broadcast module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Front control/display interface module (high level display front)	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Auto high beam control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Rear Heating ventilation and air conditioning control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Front controls interface module 'B' (front audio control panel)	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Side object detection control module - Left	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Vehicle immobilizer control module (steering column lock)	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Rear climate seat module	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Power operated tailgate	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Right side safety belt pretensioner	V1.00.001 or higher
Jaguar	XI range	2010-2012		Programming/Customization	Left side safety belt pretensioner	V1.00.001 or higher
Jaguar	XI range	2013-2015	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2013-2015	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2013-2015	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2013-2015	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2013-2015	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2013-2015	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2013-2015	ABS - ABS control module	Live Data		V1.00.001 or higher

Jaguar	XI range	2013-2015	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	AAM - Audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	NCM - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	NCM - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	NCM - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	NCM - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	REM - Rear entertainment control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	REM - Rear entertainment control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	REM - Rear entertainment control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	REM - Rear entertainment control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2013-2015	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2013-2015	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Rest of world - Service interval options	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Oil change reset	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Parking brake release to service position	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Tire pressure sensor test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Test dual battery system	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Verify battery 2 charging	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Brake bleed	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Verify keys	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Check passive keys enabled	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Injector valve test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Variable assist power steering curves programming.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Height calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Air suspension deflation.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Suspension Enable	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Suspension geometry set-up	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Drivers side window calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Passenger side window calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Sunroof calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Driver's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Passenger's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Odometer calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2013-2015	Special functions	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Speed control alignment	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Calibrate clutch	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Transfer case classification	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Oil change reset	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Reset water in fuel detection	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Turbine shut-off valve	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Exhaust gas recirculation valve	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Oxygen sensor	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Oxidation catalyst	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Purge valve self test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Evaporative system diagnostic test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Fuel prime routine	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Fuel lift pump	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	OBDDI readiness tests	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Adaptive fuel trim display	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Powertrain control module adaption clear.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Transmission control module adaption clear	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	High pressure fuel pump test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Fuel tank - Smoke test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Injector valve test	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Fuel pump supply - Enable/disable	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Engine control module unlock application	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Air path set-up routine	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Brake bleed	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Control module calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Set/un-set air suspension manufacturing/freeze mode	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Height calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Air suspension deflation.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Suspension Enable	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Suspension geometry set-up	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Headlamp calibration suspension set-up	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Ride level control module diagnostic interface.	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Ride level control module inflation (showroom)	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Recover programmed keys	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Verify keys	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Check passive keys enabled	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Check all antennas	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Immobilizer antenna unit functionality check	V1.00.001 or higher
Jaguar	XI range	2013-2015	Service	Start authorisation status	V1.00.001 or higher

Jaguar	XI range	2013-2015		Service	Smart key health check	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Headlamp control module system calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Actuator test	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Actuator initialisation	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Evaporator and heater test	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Calibrate dynamic volume control	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Test dual battery system	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Verify battery 2 charging	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Quiescent current control module internal check	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Information and entertainment system special applications	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Navigation reset	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	DVD region counter reset	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Activate television test picture	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Sunroof calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Valet mode reset	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Variable assist power steering curves programming.	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Driver's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Passenger's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Transportation mode	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Restraints build mode	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Vehicle reset	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Odometer calibration	V1.00.001 or higher
Jaguar	XI range	2013-2015		Service	Alarm trigger history	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	ABS control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Front control/display interface module (high level display front)	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Gear shift module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Auto high beam control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Rear Heating ventilation and air conditioning control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Front controls interface module 'B' (front audio control panel)	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Navigation control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Parking assist control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Parking brake control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Restraints occupant classification system module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Side object detection control module - Left	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Speed control module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Immobiliser antenna unit	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Rear climate seat module	V1.00.001 or higher
Jaguar	XI range	2013-2015		Programming/Customization	Power operated tailgate	V1.00.001 or higher
Jaguar	XI range	2016	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	PBM - Parking brake control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	PBM - Parking brake control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	PBM - Parking brake control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	PBM - Parking brake control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	BCM - Body control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	BCM - Body control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	BCM - Body control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	BCM - Body control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	GWM - Gateway module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	GWM - Gateway module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	GWM - Gateway module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	GWM - Gateway module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	HCM - Headlamp control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	HCM - Headlamp control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	HCM - Headlamp control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	HCM - Headlamp control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	OCs - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	OCs - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	OCs - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	OCs - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	RDCM - Rear differential control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	RDCM - Rear differential control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	RDCM - Rear differential control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	RDCM - Rear differential control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	TCCM - Transfer case control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	TCCM - Transfer case control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCCM - Transfer case control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCCM - Transfer case control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	TCU - Telematic control unit module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	TCU - Telematic control unit module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCU - Telematic control unit module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	TCU - Telematic control unit module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	VIM - Vehicle immobilizer control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	CHCM - Chassis control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	CHCM - Chassis control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	CHCM - Chassis control module	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	CHCM - Chassis control module	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	IPMA - Image processing control module A	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	IPMA - Image processing control module A	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	IPMA - Image processing control module A	Erase Codes		V1.00.001 or higher
Jaguar	XI range	2016	IPMA - Image processing control module A	Live Data		V1.00.001 or higher
Jaguar	XI range	2016	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	XI range	2016	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	XI range	2016	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher

Jaguar	XI range	2016 -	PAM - Parking assist control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	PSCM - Power steering control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	PSCM - Power steering control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PSCM - Power steering control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PSCM - Power steering control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	SASM - Steering angle sensor module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	SASM - Steering angle sensor module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SASM - Steering angle sensor module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SASM - Steering angle sensor module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	VDM - Vehicle dynamics control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	VDM - Vehicle dynamics control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	VDM - Vehicle dynamics control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	VDM - Vehicle dynamics control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	FCIM - Integrated control panel	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	FCIM - Integrated control panel	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	FCIM - Integrated control panel	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	FCIM - Integrated control panel	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	HVAC - Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	HVAC - Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	HVAC - Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	HVAC - Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	IMC - InControl Touch Pro infotainment master controller	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	IMC - InControl Touch Pro infotainment master controller	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	IMC - InControl Touch Pro infotainment master controller	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	IMC - InControl Touch Pro infotainment master controller	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	IPMB - Image processing module B	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	IPMB - Image processing module B	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	IPMB - Image processing module B	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	IPMB - Image processing module B	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RHVAC - Rear Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	SODL - Side object detection control module - Left	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	SODL - Side object detection control module - Left	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SODL - Side object detection control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	PDM - Passenger's door module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	PDM - Passenger's door module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PDM - Passenger's door module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PDM - Passenger's door module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	PSM - Passenger's seat module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	PSM - Passenger's seat module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PSM - Passenger's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	PSM - Passenger's seat module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	RFA - Keyless vehicle module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	RFA - Keyless vehicle module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RFA - Keyless vehicle module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RFA - Keyless vehicle module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	RGTM - Rear gate / trunk module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	RGTM - Rear gate / trunk module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RGTM - Rear gate / trunk module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RGTM - Rear gate / trunk module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	RISM - Rear seat - Control module - Left	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	RISM - Rear seat - Control module - Left	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RISM - Rear seat - Control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RISM - Rear seat - Control module - Left	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	RRSM - Rear seat - Control module - Right	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	RRSM - Rear seat - Control module - Right	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RRSM - Rear seat - Control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	RRSM - Rear seat - Control module - Right	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	AAM - InControl Touch Pro audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	AAM - InControl Touch Pro audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	AAM - InControl Touch Pro audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	AAM - InControl Touch Pro audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	ISC - InControl Touch Pro infotainment slave controller	ECU Information	V1.00.001 or higher
Jaguar	XI range	2016 -	ISC - InControl Touch Pro infotainment slave controller	Read Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	ISC - InControl Touch Pro infotainment slave controller	Erase Codes	V1.00.001 or higher
Jaguar	XI range	2016 -	ISC - InControl Touch Pro infotainment slave controller	Live Data	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Oil change reset	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Parking brake pad replacement - Release to service position	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Parking brake pad replacement - Exit maintenance mode application	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Parking brake activation	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Yaw rate sensor calibration.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Test internal backup battery	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Battery replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Injector valve test	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Automatic high beam camera calibration	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Passengers seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Rear right seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -	Special functions	Rear Left seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Speed control alignment	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Injector replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Idle speed test.	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Oil service counter reset	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Injector valve test	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Passenger's seat calibration.	V1.00.001 or higher
Jaguar	XI range	2016 -	Service	Seat cushion replacement	V1.00.001 or higher

Jaguar	XI range	2016 -		Service	Rear seat calibration - Right	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Rear seat calibration - Left	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Passengers seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Rear right seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Rear Left seat massage on demand self test	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Automatic high beam camera calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Test internal backup battery	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Drivers side window calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Passenger side window calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Steering column calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Sunroof calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Driver's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Passenger's side - Rear door blind initialisation	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Service interval reset.	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Vehicle reset	V1.00.001 or higher
Jaguar	XI range	2016 -		Service	Battery replacement	V1.00.001 or higher
Jaguar	X-Type	2001-2003	ECM - Engine control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ECM - Engine control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ECM - Engine control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ECM - Engine control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ABS - Anti-lock braking system	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ABS - Anti-lock braking system	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ABS - Anti-lock braking system	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ABS - Anti-lock braking system	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	IP - Instrument pack	ECU information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	FETM - Audio unit	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	FETM - Audio unit	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	FETM - Audio unit	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	FETM - Audio unit	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	GEM - General electronics control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	GEM - General electronics control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	GEM - General electronics control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	GEM - General electronics control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ARM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ADHLS - Headlamp levelling system.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ADHLS - Headlamp levelling system.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ADHLS - Headlamp levelling system.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	ADHLS - Headlamp levelling system.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2001-2003	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2001-2003	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2001-2003		Special functions	Program keys.	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Special functions	Steering angle sensor calibration	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	ABS control module	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Steering angle sensor calibration	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Program new transponders	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Program additional transponders	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Last alarm activations	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Program keys.	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Transmission control module drive cycle	V1.00.001 or higher
Jaguar	X-Type	2001-2003		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	X-Type	2004 -	ECM - Engine control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	ECM - Engine control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ECM - Engine control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ECM - Engine control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	IP - Instrument pack	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	IP - Instrument pack	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	IP - Instrument pack	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	IP - Instrument pack	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	ATC - Climate control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	ATC - Climate control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ATC - Climate control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ATC - Climate control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	FETM - Audio unit	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	FETM - Audio unit	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	FETM - Audio unit	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	FETM - Audio unit	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	GEM - General electronics control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	GEM - General electronics control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	GEM - General electronics control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	GEM - General electronics control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	NAV - Navigation control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	NAV - Navigation control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	NAV - Navigation control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	NAV - Navigation control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	ADHLS - Headlamp levelling system.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	ADHLS - Headlamp levelling system.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ADHLS - Headlamp levelling system.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ADHLS - Headlamp levelling system.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004 -	ARM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004 -	ARM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004 -	ARM - Restraints control module	Erase Codes		V1.00.001 or higher

Jaguar	X-Type	2004-	ARM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-	FFH - Fuel fired heater module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	FFH - Fuel fired heater module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	FFH - Fuel fired heater module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	ISM - Intrusion sensor module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	ISM - Intrusion sensor module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	ISM - Intrusion sensor module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	ISM - Intrusion sensor module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-	PAM - Parking aid control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	PAM - Parking aid control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	PAM - Parking aid control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	PAM - Parking aid control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-	AMP - Amplifier	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	AMP - Amplifier	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	AMP - Amplifier	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	AMP - Amplifier	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-	CPM - Cellular telephone control module	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	CPM - Cellular telephone control module	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	CPM - Cellular telephone control module	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	CPM - Cellular telephone control module	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-	VACM - Voice activation control module.	ECU Information		V1.00.001 or higher
Jaguar	X-Type	2004-	VACM - Voice activation control module.	Read Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	VACM - Voice activation control module.	Erase Codes		V1.00.001 or higher
Jaguar	X-Type	2004-	VACM - Voice activation control module.	Live Data		V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Oil dilution reset	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Program keys.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Immobilization set-up	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Display injector correction factors.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Injector cycle test	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Injector leak back test	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Injector correction factors.	V1.00.001 or higher
Jaguar	X-Type	2004-		Special functions	Steering angle sensor calibration	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	ABS control module	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Steering angle sensor calibration	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Tire pressure monitor receiver calibration.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Tire pressure monitor confirmation application.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Brake bleed.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Injector correction factors.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Program new transponders	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Program additional transponders	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Program keys.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Immobilization set-up	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Last alarm activations	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Service interval reset.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Oil dilution reset	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Delta pressure sensor replacement	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Display injector correction factors.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Injector cycle test	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Injector leak back test	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Inlet metering valve	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module adaptation clear.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module clear oil degradation counter	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module clear self-learning data	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module drive cycle	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module neutral learn	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Transmission control module set adaptation mode	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Reset the diesel particulate filter stored values.	V1.00.001 or higher
Jaguar	X-Type	2004-		Service	Evaporative system leak check	V1.00.001 or higher
Jaguar	XE	2016	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	BCM - Body control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	BCM - Body control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	BCM - Body control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	BCM - Body control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	GWM - Gateway module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	GWM - Gateway module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	GWM - Gateway module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	GWM - Gateway module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	OCS - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	OCS - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	OCS - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	OCS - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	TCU - Telematic control unit module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	TCU - Telematic control unit module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	TCU - Telematic control unit module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	TCU - Telematic control unit module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	VIM - Vehicle immobilizer control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	ATCM - All terrain control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	ATCM - All terrain control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	ATCM - All terrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	ATCM - All terrain control module	Live Data		V1.00.001 or higher
Jaguar	XE	2016	CHCM - Chassis control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2016	CHCM - Chassis control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2016	CHCM - Chassis control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2016	CHCM - Chassis control module	Live Data		V1.00.001 or higher

Jaguar	XE	2016	IPMA - Image processing control module A	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	IPMA - Image processing control module A	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	IPMA - Image processing control module A	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	IPMA - Image processing control module A	Live Data	V1.00.001 or higher
Jaguar	XE	2016	PAM - Parking assist control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	PAM - Parking assist control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	PAM - Parking assist control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	PAM - Parking assist control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	PSCM - Power steering control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	PSCM - Power steering control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	PSCM - Power steering control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	PSCM - Power steering control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	SASM - Steering angle sensor module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	SASM - Steering angle sensor module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	SASM - Steering angle sensor module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	SASM - Steering angle sensor module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	DDM - Driver's door module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	DDM - Driver's door module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	DDM - Driver's door module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	DDM - Driver's door module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	DRDM - Driver's (side) rear door module.	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	DRDM - Driver's (side) rear door module.	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	DRDM - Driver's (side) rear door module.	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	DRDM - Driver's (side) rear door module.	Live Data	V1.00.001 or higher
Jaguar	XE	2016	DSM - Driver's seat module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	DSM - Driver's seat module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	DSM - Driver's seat module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	DSM - Driver's seat module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	PDM - Passenger's door module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	PDM - Passenger's door module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	PDM - Passenger's door module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	PDM - Passenger's door module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	PRDM - Passenger's (side) rear door module.	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	PRDM - Passenger's (side) rear door module.	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	PRDM - Passenger's (side) rear door module.	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	PRDM - Passenger's (side) rear door module.	Live Data	V1.00.001 or higher
Jaguar	XE	2016	RFA - Keyless vehicle module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	RFA - Keyless vehicle module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	RFA - Keyless vehicle module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	RFA - Keyless vehicle module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	RGTM - Rear gate / trunk module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	RGTM - Rear gate / trunk module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	RGTM - Rear gate / trunk module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	RGTM - Rear gate / trunk module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	TBM - Deployable towbar control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	TBM - Deployable towbar control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	TBM - Deployable towbar control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	TBM - Deployable towbar control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	AHU - InControl Touch audio head unit	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	AHU - InControl Touch audio head unit	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	AHU - InControl Touch audio head unit	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	AHU - InControl Touch audio head unit	Live Data	V1.00.001 or higher
Jaguar	XE	2016	AUCM - Head-up display cooling fan module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	AUCM - Head-up display cooling fan module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	AUCM - Head-up display cooling fan module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	AUCM - Head-up display cooling fan module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	CAV - Connect and view module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	CAV - Connect and view module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	CAV - Connect and view module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	CAV - Connect and view module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	FCDIM - Front control/display interface module (high level display front)	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	FCDIM - Front control/display interface module (high level display front)	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	FCDIM - Front control/display interface module (high level display front)	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	FCDIM - Front control/display interface module (high level display front)	Live Data	V1.00.001 or higher
Jaguar	XE	2016	FCIM - Integrated control panel	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	FCIM - Integrated control panel	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	FCIM - Integrated control panel	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	FCIM - Integrated control panel	Live Data	V1.00.001 or higher
Jaguar	XE	2016	HUD - Head up display	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	HUD - Head up display	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	HUD - Head up display	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	HUD - Head up display	Live Data	V1.00.001 or higher
Jaguar	XE	2016	HVAC - Heating ventilation and air conditioning control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	HVAC - Heating ventilation and air conditioning control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	HVAC - Heating ventilation and air conditioning control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	HVAC - Heating ventilation and air conditioning control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	IPMB - Image processing module B	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	IPMB - Image processing module B	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	IPMB - Image processing module B	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	IPMB - Image processing module B	Live Data	V1.00.001 or higher
Jaguar	XE	2016	NAV - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	NAV - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	NAV - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	NAV - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	SODL - Side object detection control module - Left	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	SODL - Side object detection control module - Left	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	SODL - Side object detection control module - Left	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	SODL - Side object detection control module - Left	Live Data	V1.00.001 or higher
Jaguar	XE	2016	SODR - Side object detection control module - Right	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	SODR - Side object detection control module - Right	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	SODR - Side object detection control module - Right	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	SODR - Side object detection control module - Right	Live Data	V1.00.001 or higher
Jaguar	XE	2016	AAM - Audio amplifier module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	AAM - Audio amplifier module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	AAM - Audio amplifier module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	AAM - Audio amplifier module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	ACM - Audio front control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	ACM - Audio front control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	ACM - Audio front control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	ACM - Audio front control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	DABM - Digital audio broadcast module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	DABM - Digital audio broadcast module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	DABM - Digital audio broadcast module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	DABM - Digital audio broadcast module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	NCM - Navigation control module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	NCM - Navigation control module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	NCM - Navigation control module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	NCM - Navigation control module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	SRM - Satellite audio unit module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	SRM - Satellite audio unit module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	SRM - Satellite audio unit module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	SRM - Satellite audio unit module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	TVM - Television module	ECU Information	V1.00.001 or higher
Jaguar	XE	2016	TVM - Television module	Read Codes	V1.00.001 or higher
Jaguar	XE	2016	TVM - Television module	Erase Codes	V1.00.001 or higher
Jaguar	XE	2016	TVM - Television module	Live Data	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Service interval reset.	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Oil service counter reset	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Parking brake pad replacement - Release to service position	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Parking brake pad replacement - Exit maintenance mode application	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Parking brake activation	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Apply and release electric park brake	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XE	2016	Special functions	Tire pressure monitor sensor identification display	V1.00.001 or higher

Jaguar	XE	2016		Special functions	Steering column calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Test internal backup battery	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Battery replacement	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Throttle valve actuator	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Idle speed test.	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Injector replacement	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Injector valve test	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Automatic high beam camera calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Driver's seat calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Seat cushion replacement	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Roof Blind calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Sunroof calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XE	2016		Special functions	Door window calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Speed control alignment	V1.00.001 or higher
Jaguar	XE	2016		Service	Throttle valve actuator	V1.00.001 or higher
Jaguar	XE	2016		Service	Injector replacement	V1.00.001 or higher
Jaguar	XE	2016		Service	Diesel particulate filter differential pressure sensor replacement	V1.00.001 or higher
Jaguar	XE	2016		Service	Idle speed test.	V1.00.001 or higher
Jaguar	XE	2016		Service	Diesel particulate filter dynamic regeneration	V1.00.001 or higher
Jaguar	XE	2016		Service	Diesel particulate filter replacement	V1.00.001 or higher
Jaguar	XE	2016		Service	Oil service counter reset	V1.00.001 or higher
Jaguar	XE	2016		Service	Throttle valve actuator replacement	V1.00.001 or higher
Jaguar	XE	2016		Service	Injector valve test	V1.00.001 or higher
Jaguar	XE	2016		Service	Driver's seat calibration.	V1.00.001 or higher
Jaguar	XE	2016		Service	Seat cushion replacement	V1.00.001 or higher
Jaguar	XE	2016		Service	Driver's seat massage on demand self test	V1.00.001 or higher
Jaguar	XE	2016		Service	Automatic high beam camera calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Telematics control module battery replacement reset	V1.00.001 or higher
Jaguar	XE	2016		Service	Test internal backup battery	V1.00.001 or higher
Jaguar	XE	2016		Service	Roof Blind calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Steering column calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Sunroof calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Tailgate/trunk calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Power steering soft-lock end stops reset routine	V1.00.001 or higher
Jaguar	XE	2016		Service	Door window calibration	V1.00.001 or higher
Jaguar	XE	2016		Service	Lock steering tune to vehicle	V1.00.001 or higher
Jaguar	XE	2016		Service	Tire pressure sensor replacement.	V1.00.001 or higher
Jaguar	XE	2016		Service	Tire pressure monitor sensor identification display	V1.00.001 or higher
Jaguar	XE	2016		Service	Pre-delivery inspection.	V1.00.001 or higher
Jaguar	XE	2016		Service	Service interval reset.	V1.00.001 or higher
Jaguar	XE	2016		Service	Vehicle reset	V1.00.001 or higher
Jaguar	XE	2016		Service	Battery replacement	V1.00.001 or higher
Jaguar	XE	2017-	PCM - Powertrain control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	PCM - Powertrain control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	PCM - Powertrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	PCM - Powertrain control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	TCM - Transmission control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	TCM - Transmission control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCM - Transmission control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCM - Transmission control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	ABS - ABS control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	ABS - ABS control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	ABS - ABS control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	ABS - ABS control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	RCM - Restraints control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	RCM - Restraints control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	RCM - Restraints control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	RCM - Restraints control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	IPC - Instrument cluster control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	IPC - Instrument cluster control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	IPC - Instrument cluster control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	IPC - Instrument cluster control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	TPM - Tire pressure monitor module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	TPM - Tire pressure monitor module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	TPM - Tire pressure monitor module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	TPM - Tire pressure monitor module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	BCM - Body control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	BCM - Body control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	BCM - Body control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	BCM - Body control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	CCM - Speed control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	CCM - Speed control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	CCM - Speed control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	CCM - Speed control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	GSM - Gear shift module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	GSM - Gear shift module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	GSM - Gear shift module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	GSM - Gear shift module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	GWM - Gateway module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	GWM - Gateway module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	GWM - Gateway module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	GWM - Gateway module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	OCS - Restraints occupant classification system module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	OCS - Restraints occupant classification system module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	OCS - Restraints occupant classification system module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	OCS - Restraints occupant classification system module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	TCCM - Transfer case control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	TCCM - Transfer case control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCCM - Transfer case control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCCM - Transfer case control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	TCU - Telematic control unit module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	TCU - Telematic control unit module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCU - Telematic control unit module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	TCU - Telematic control unit module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	VIM - Vehicle immobilizer control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	VIM - Vehicle immobilizer control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	VIM - Vehicle immobilizer control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	VIM - Vehicle immobilizer control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	ATCM - All terrain control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	ATCM - All terrain control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	ATCM - All terrain control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	ATCM - All terrain control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	CHCM - Chassis control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	CHCM - Chassis control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	CHCM - Chassis control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	CHCM - Chassis control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	IPMA - Image processing control module A	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	IPMA - Image processing control module A	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	IPMA - Image processing control module A	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	IPMA - Image processing control module A	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	PAM - Parking assist control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	PAM - Parking assist control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	PAM - Parking assist control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	PAM - Parking assist control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	PSCM - Power steering control module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	PSCM - Power steering control module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	PSCM - Power steering control module	Erase Codes		V1.00.001 or higher
Jaguar	XE	2017-	PSCM - Power steering control module	Live Data		V1.00.001 or higher
Jaguar	XE	2017-	SASM - Steering angle sensor module	ECU Information		V1.00.001 or higher
Jaguar	XE	2017-	SASM - Steering angle sensor module	Read Codes		V1.00.001 or higher
Jaguar	XE	2017-	SASM - Steering angle sensor module	Erase Codes		V1.00.001 or higher

