

BENZ IDL Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Chassis	Model Year	IDL
CLA(117)	ALL	●
SL(129)	Up to 08/99	●
SL(129)	As Of 09/99	●
S(140)	ALL	●
GLA(156)	ALL	●
ML(163)	ALL	●
M(164)	ALL	●
GL(164)	ALL	●
ML(166)	ALL	●
GL(166)	ALL	●
A(168)	ALL	●
A(169)	Up To 11/2005	●
A(169)	As Of 12/2005	●
SLK(170)	16-PIN	●
SLK(170)	38-PIN	●
SLK(171)	Up To 05/2005	●
SLK(171)	As Of 06/2005	●
SLK(172)	ALL	●
SLR(199)	ALL	●
C(202)	Up to 05/97	●
C(202)	As Of 06/97	●
CLC(203)	Up To 08/2003	●
CLC(203)	As Of 09/2003	●
CLC(203)	As Of 01/2008	●
C(204)	ALL	●
GLK(204)	ALL	●
C(205)	ALL	●
E(207)	ALL	●
CLK(208)	ALL	●
CLK(209)	Up To 03/2004	●
CLK(209)	As Of 04/2004	●
E(210)	Up to 02/97	●
E(210)	As Of 03/97	●
E(211)	Up To 05/2005	●
E(211)	From 06/2005 To 05/2006	●
E(211)	As Of 06/2006	●
E(212)	ALL	●
CL(215)	Up To 08/2002	●
CL(215)	As Of 09/2002	●
CL(216)	ALL	●
S(217)	ALL	●
CLS(218)	ALL	●
CLS(219)	Up To 05/2005	●
CLS(219)	From 06/2005 To 05/2006	●
CLS(219)	As Of 06/2006	●
S(220)	Up To 08/2002	●
S(220)	As Of 09/2002	●

S(221)	Up To 06/2009	●
S(221)	As Of 07/2009	●
S(222)	ALL	●
SL(230)	Up To 08/2003	●
SL(230)	From 09/2003 To 02/2008	●
SL(230)	AS Of 03/2008	●
SL(231)	ALL	●
Maybach(240)	Up To 08/2006	●
Maybach(240)	As Of 09/2006	●
B(245)	Up To 11/2005	●
B(245)	As Of 12/2005	●
R(251)	ALL	●
GLC(253)	ALL	●
G(463)	Up To 03/2004(16-PIN)	●
G(463)	From 04/2004 To 08/2006(16-PIN)	●
G(463)	From 09/2006 To 02/2007(16-PIN)	●
G(463)	From 03/2007 To 12/2011(16-PIN)	●
G(463)	From 01/2012 To 12/2017(16-PIN)	●
G(463)	38-PIN	●

IDL Function List

CO Setting For Vehicles Without TWC
CO setting for vehicles without TWC(Left cylinder bank)
CO setting for vehicles without TWC(Right cylinder bank)
Correction programming of specified idle speed
Correction programming of specified idle speed in selector lever position 'P' or 'N'
Correction programming of specified idle speed with gear range engaged
Idle speed set value
Idling Specified Speed With Gear Engaged
Idling Specified Speed With Selector Lever In Position P Or N
Perform correction programming(CO setting for models without TWC)
Perform correction programming(Idling speed Selector lever Drive position)
Perform correction programming(Idling speed Selector lever P/N)