

INFINITI\_V01.10 Daig Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Model Year			
EX25	ALL			
EX35	ALL			
EX37	ALL			
FX30d	ALL			
FX45	ALL			
FX50	ALL			
G20	ALL			
G35	ALL			
G37	ALL			
I30	ALL			
I35	ALL			
M25/M37	ALL			
M35/M45	ALL			
M37/M56	ALL			
M37/M56/M30d	ALL			
M45	ALL			
Q45	ALL			
QX4	ALL			
QX56	ALL			
Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData
Engine	●	●	●	●
Transmission	●	●	●	●
ABS	●	●	●	●
Air Bag	●	●	●	●
Meter/M&A	●	●	●	●
SUB Meter	●	●	●	●
EPS/DAST 3	●	●	●	●
Air Pressure Monitor	●	●	●	●
HVAC	●	●	●	●
BCM	●	●	●	●
Motor Control	●	●	●	●
ICC/ADAS	●	●	●	●
All Mode AWD/4WD	●	●	●	●
E-4WD	●	●	●	●
4WAS (MAIN) /RAS/HICAS	●	●	●	●
4WAS (Front)	●	●	●	●
Difference Lock	●	●	●	●
CAN Gateway	●	●	●	●
Accele Pedal ACT	●	●	●	●
Brake	●	●	●	●
Chassis Control	●	●	●	●
Adaptive Light	●	●	●	●
Head Lamp Levelizer	●	●	●	●
Auto Drive Position	●	●	●	●

Intelligent Key	●	●	●	●
Smart Entrance	●	●	●	●
Auto Slide Door	●	●	●	●
Auto Slide Door Right	●	●	●	●
Auto Back Door	●	●	●	●
Precrash Seatbelt	●	●	●	●
Convertible Roof	●	●	●	●
EV/HEV	●	●	●	●
HV Battery	●	●	●	●
Charger/PD Module	●	●	●	●
PTC Heater	●	●	●	●
Laser/Radar	●	●	●	●
Side Radar Left	●	●	●	●
Side Radar Right	●	●	●	●
Lane Camera	●	●	●	●
Rearview Camera	●	●	●	●
S/Blind Camera	●	●	●	●
Multi Display	●	●	●	●
Multi AV	●	●	●	●
Sonar	●	●	●	●
BSW/Buzzer	●	●	●	●
EHS/PKB	●	●	●	●
IPDM E/R	●	●	●	●
BAC	●	●	●	●
DIU	●	●	●	●
Shift	●	●	●	●
E-SUS	●	●	●	●
ANC	●	●	●	●
Telematics	●	●	●	●
HAS	●	●	●	●
AVM	●	●	●	●
DAST 1	●	●	●	●
DAST 2	●	●	●	●
Cluster	●	●	●	●
PMAS	●	●	●	●
Radio	●	●	●	●
VSP	●	●	●	●
Nats Immu	●	●	●	●
Air Levelizer	●	●	●	●
Motor Assist	●	●	●	●