

VOLVO BMS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Model	Year	BMS
C30		2007	●
C30		2008	●
C30		2009	●
C30		2010	●
C30		2011	●
C30		2012	●
C30		2013	●
C70		2006	●
C70		2007	●
C70		2008	●
C70		2009	●
C70		2010	●
C70		2011	●
C70		2012	●
C70		2013	●
S40		2004.05 -	●
S40		2005	●
S40		2006	●
S40		2007	●
S40		2008	●
S40		2009	●
S40		2010	●
S40		2011	●
S40		2012	●
S60		2001	●
S60		2002	●
S60		2003	●
S60		2004	●
S60		2005	●
S60		2006	●
S60		2007	●
S60		2008	●
S60		2009	●
S60		2010	●
S60		2011	●
S60		2012	●
S60		2013	●
S60		2014	●
S60		2015	●
S60		2016	●
S60		2017	●
S60		2018	●

S80	1999	●
S80	2000	●
S80	2001	●
S80	2002	●
S80	2003	●
S80	2004	●
S80	2005	●
S80	2006	●
S80	2007	●
S80	2008	●
S80	2009	●
S80	2010	●
S80	2011	●
S80	2012	●
S80	2013	●
S80	2014	●
S80	2015	●
S80	2016	●
S90	2018	●
S90L	2018	●
S90L	2019	●
V40	2013	●
V40	2014	●
V40	2015	●
V40	2016	●
V40	2017	●
V40	2018	●
V50	2004	●
V50	2005	●
V50	2006	●
V50	2007	●
V50	2008	●
V50	2009	●
V50	2010	●
V50	2011	●
V50	2012	●
V60	2011	●
V60	2012	●
V60	2013	●
V60	2014	●
V60	2015	●
V60	2016	●
V60	2017	●
V60	2018	●
V70	2000.05 -	●
V70	2001	●
V70	2002	●
V70	2003	●
V70	2004	●
V70	2005	●
V70	2006	●
V70	2007	●
V70	-2008.05	●
V70	2008.05 -	●
V70	2009	●
V70	2010	●
V70	2011	●
V70	2012	●
V70	2013	●
V70	2014	●
V70	2015	●
V70	2016	●

V90	2018	●
V90 Cross Country (17-)	2018	●
XC40	2018	●
XC60	2009	●
XC60	2010	●
XC60	2011	●
XC60	2012	●
XC60	2013	●
XC60	2014	●
XC60	2015	●
XC60	2016	●
XC60	2017	●
XC60	2018	●
XC70	2001	●
XC70	2002	●
XC70	2003	●
XC70	2004	●
XC70	2005	●
XC70	2006	●
XC70	2007	●
XC70	2008	●
XC70	2009	●
XC70	2010	●
XC70	2011	●
XC70	2012	●
XC70	2013	●
XC70	2014	●
XC70	2015	●
XC70	2016	●
XC90	2003	●
XC90	2004	●
XC90	2005	●
XC90	2006	●
XC90	2007	●
XC90	2008	●
XC90	2009	●
XC90	2010	●
XC90	2011	●
XC90	2012	●
XC90	2013	●
XC90	2014	●
XC90	2015	●
XC90	2016	●
XC90 NEW MODEL (16-)	2018	●

BMS Function List

Reinstalling The Reserve Battery

Resetting The Information To Zero On Power Supply When Replacing The Battery

Resetting The Information To Zero On Power Supply When Replacing The Battery Monitoring Sensor (BMS)